

Dr. Fixit Crack-X Paste



READY TO USE CRACK FILLER FOR INTERNAL & EXTERNAL SURFACE CRACKS IN PLASTER

Description

Dr. Fixit Crack-X Paste is composed of high quality weather durable acrylic emulsion polymer, properly selected graded fillers, light fast pigment & additives. It is a single pack, ready to use flexible putty for filling the cracks in plastered surfaces because it has excellent bonding, ease of application, water resistance, aesthetic appearance & durability.

Specification

Meets the requirements of ASTM C 834 - 91 standard.

Areas of Application

- Internal & external Plastered brick masonry wall cracks of upto 5mm width.

Features & Benefits

- **Consistency** - Paste form, without sagging.
- **Ease of application** - Easy to apply by putty knife similar to conventional putties.
- **Flexibility** - Flexible, therefore does not crack & accommodates minor movements in cracks.
- **VOC** - Water based with very low VOC hence eco-friendly.
- **Application advantage** - Can be applied on damp surfaces but not on cracks with running water.
- **Paint ability** - Over coatable by any type of polymer based paints, after 24 hours.
- **Staining** - Non-staining.
- **Bonding** - Excellent adhesion with cementitious surface.
- **Durability** - Excellent resistance to UV & atmospheric conditions.
- **Tinting ability** - It can be tinted using water-based stainers.
- **Toxicity** - Non toxic & harmless to hands.

Method of Application

1 SURFACE PREPARATION

- Surface must be free from dust, oil, grease, and loose particles etc. Moisten the surface before applying Dr. Fixit Crack-X Paste.
- Fine hair line cracks must be widened up to 1 mm minimum by using scraper and then filled
- For filling Dr. Fixit Crack-X Paste on the internal surface, existing POP or painter's putty must be removed till plaster surface is exposed.
- For porous surfaces, apply primer coat prepared with Dr. Fixit Crack-X Paste and water in 1:1 proportion over the crack. Fill Dr. Fixit Crack-X Paste when the surface is tacky and not dried completely.

1 APPLICATION

- Press Dr. Fixit Crack-X Paste firmly into the crack with a spatula or putty knives and level with the surface.
- Care must be taken to avoid formation of cavities or bubbles during application.
- Allow it to set for 24 hours and then apply another coat of Dr. Fixit Crack-X Paste.
- Further POP or painter's putty application can be taken up once it is fully dry.
- For best results allow Dr. Fixit Crack-X Paste to cure for 7 days.

Dr. Fixit Crack-X Paste

READY TO USE CRACK FILLER FOR INTERNAL & EXTERNAL SURFACE CRACKS IN PLASTER

Precautions & Limitations

- Should not be used for cracks more than 5 mm thick.
- Not for application in cracks in structural members, expansion joints & separation gaps.
- Not for cracks in POP or painter's putty.
- For application below 10oC, drying time will be delayed.
- Container to be tightly closed after application.

Cleaning

- Clean tools & equipments and hands with soap and warm water, immediately after use.

Technical Information

PROPERTIES	SPECIFICATION	RESULTS
Appearance		Smooth & thick paste
Colour		White
Sp. Gravity @ 30°C, gms/ml	ASTM D : 3800 - 79	1.40 ± 0.02
Consistency		Viscous paste
Non volatile content, %	ASTM D : 1010	75 -80
Tack free time, Minutes	ASTM D : 2377	30 - 40
Vertical slump. mm	ASTM D : 2202	Nil
Service temp range, °C		-15 to + 80
Extension recovery, %	ASTM C : 736	Min 75
Freeze / thaw stability, cycles		Passes 5
Volume shrinkage, %	ASTM C 1241	20
Movement accommodation factor, %		+ 10
Water resistance,		Excellent

PACKING

200, 500 gms, 1 kg & 5 kg.

Shelf Life & Storage

- Shelf life is 12 months from date of manufacturing in unopened containers.
- Store at cool & dry place, away from sun heat .

Coverage

- 25-30 running meter/kg (for a depth of 5mm and width of 5 mm).

Health & Safety Precautions

- Use rubber hand gloves & safety goggles, while using Dr Fixit Crack X paste.
- In case of contact with skin, wash with plenty of water.
- Keep out of reach of children's.
- Should any of the products be accidentally swallowed do not induce omitting but call for medical assistance, immediately.

Dr. Fixit Crack-X Paste



READY TO USE CRACK FILLER FOR INTERNAL & EXTERNAL SURFACE CRACKS IN PLASTER

Other Product Categories Available

Dr. Fixit has wide range of Waterproofing & Construction chemicals which includes,

- Waterproofing Products
- Repair Products
- Sealants
- Flooring Products
- Exterior Coating Products
- Tile Fixing Range
- Concrete Admixtures
- Grouts



Pidilite Industries Limited

Construction Chemicals Division
Ramkrishna Mandir Road
Post Box No. 17411
Andheri (E) Mumbai 400059 INDIA
Tel +91-22-2835 7000 • Fax +91-22-2835 7008
website www.doctor-fixit.com • E-mail drfixit@pidilite.com
Toll Free No.: 1800-22-5502

DISCLAIMER The product information & application details given by the company & its agents has been provided in good faith & meant to serve only as a general guideline during usage. Users are advised to carry out tests & take trials to ensure on the suitability of products meeting their requirement prior to full scale usage of our products. Since the correct identification of the problems, quality of other materials used and the on-site workmanship are factors beyond our control, there are no expressed or implied guarantee / warranty as to the results obtained. The company does not assume any liability or consequential damage for unsatisfactory results, arising from the use of our products.